
Processing Guidelines

Printing guidelines

LFM344 is compatible with ColorWave printers with Océ CrystalPoint® technology. High quality print-modes are recommended for best results. Use the ODT (Oce Delivery tray) when printing LFM344. Do not use the TDT (Top Delivery Tray) LFM344 is too soft/weak. It is recommended to handle the media with cotton gloves. Make sure that the media does not come into contact with grease, oil, silicon, and dirt to avoid printing defects. Insert media with care in the printers. Incorrect loading can cause skewing or creasing. Allow material to adapt to room conditions for 24 hours before printing. It is recommended to calibrate the printer before printing and to make a test print. Print results will vary for different printers. Ink/toner restrictions and printer settings have to be set for specific printers to obtain the best results. Canon colour profiles include recommended ink restrictions and printer settings for Canon supported printers.

Application guidelines

This banner material can be stitched, punched, perforated, and grommet. Avoid folding a printed banner. Hard creases may not flatten out during installations. When used for banners or other hanging applications, hemming the edges is recommended. Standard high-tack banner tape can be used as well as sewing. If sewn, it is recommended that the banners are stitched hem side up so that the sewing machine comes into contact only with the reverse surface of the banner. When applying grommets, they should be inserted in double-hemmed edges. Corner grommets should be placed where the length and width hems cross, so that the grommet goes through four layers.

Standard disclaimer:

All specifications subject to change without notice. All company and/or product names are trademarks and/or registered trademarks of their respective manufacturers in their markets and/or countries.